

# Tractor Cab Cleaning and Disinfecting

Clean and disinfect these high-touch surfaces. This is especially important when multiple employees are using the same equipment.

**Door handles and handle bars leading into cabs**  
The entire handle bar and release lever/button outside and inside the cab. If you utilize both doors, disinfect all the door handles.

**Light switches, windshield wipers, turn signals, steering adjustment levers, ignition key/button and drive/neutral/reverse levers on the steering column**  
Some levers are separate from the steering column.

**Engine speed slider, gear shifter and throttle**  
Some are sliders; others are throttle arms on the steering column.

**Monitors and screens**  
Follow your owners manual, Do not use water.

**Hydraulic levers/arms**  
Most tractors have at least two or three.

**Joystick**  
If your tractor has a loader attachment

**Temperature/climate controls and additional buttons and switches**  
If you open your rear or side windows for fresh air, wipe down the window handles.

**Power take-off switch/knob/lever**  
Tractors may have levers that switch from 540 to 1000 RPMs. In newer tractors, PTO controls are yellow.

**Three-point arms**  
For tractors with these, clean and disinfect the buttons or levers.

**Radio and seat adjuster**  
Not visible in photo, but clean and disinfect.

**Arm rests, hand controls, seat belt buckle, parking brake and seat adjusting levers**  
Clean and disinfect both arm rests and the hand controls if arm controls on hand rest. If multiple employees utilize the same tractor, the seat will likely be adjusted each time, so clean and disinfect the seat adjusting lever/switch/knob.

**Steering wheel**  
Some have brodie knobs (spinner knobs) attached. Clean and disinfect both.



Tractor photo courtesy of RDO Equipment Co.